



## How to install Rhino PCI cards in Trixbox 2.2

1. Boot the PC and log in as “root” or other user that has appropriate software build privileges.
2. Install the Rhino RPM's:  
**yum -y install rhino-`uname -r`**  
press ENTER
3. reboot

***Note: genzaptelconf ONLY works in Trixbox 2.2 and later.***

4. Type the following for analog cards:

```
genzaptelconf
```

**For Digital Cards please skip to configuring zaptel.conf and zapata.conf**